

### 1.1 Inserting a nanoSIM into Geo+

(not included in delivery)

Before inserting the SIM card, make sure that the PIN code request is deactivated. Open the device by unscrewing the screws that close the rear door, insert the nano-SIM into the slot and screw the screws back in.  
screws. Charge the battery for at least 8 hours.

---

### 1.2 Changing the time setting

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text:**

**TZ+01** (for use of summer time, winter time) or **TZ+02** (for use of summer time, summer time)

---

### 1.3 Programming the first emergency number

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text: A1,1,nnnnnnnn**

(where nnnnnnn is the first number Geo+ will call in the event of an emergency); SMS received if configured correctly: **Emergency number setting 1 OK!**

---

### 1.4 Programming successive emergency numbers (SECOND TO TENTH)

**Send an SMS to the telephone number of the SIM inserted in Geo+ with the text:**

**A2,1,1,nnnnnnnn** (where nnnnnnn is the number that Geo+ will call in the event of an emergency);

**Continue in the configuration of subsequent numbers by replacing A2 with A3, A4, A5, A6, A7, A8, A9, A10**  
SMS received if configured correctly: **Emergency number setting X OK!**

---

### 1.5 Ask Geo+ for your current position in Google Maps format

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text: LOC**

Geo+ will reply with the message indicating date, time and location.

**Clicking on the google link will open the map with the geographical location of Geo+**

---

### 1.6 Enabling numbers that can call Geo+

Geo+ can receive calls from emergency numbers only or from any number To allow calls to Geo+ to the configured emergency numbers only

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text: callin1**

To allow calls to Geo+ to all telephone numbers

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text: callin0**

---

### 1.7 Fall Alarm

Geo+ is already preconfigured with fall alarm active To eliminate the automatic fall alarm:

**Send an SMS to the phone number of the SIM inserted in Geo+ with the text: FLO**

---

**N.B.:** Between one call and the next there will be a 10-second delay, during which you can interrupt the sequence or cancel the alarm by simply pressing the SOS button. Contacts receiving emergency calls can also interrupt the alarm sequence by answering the call and then pressing '1' on the keypad of their mobile phone or smartphone.

VEBIRO Srl is in no way liable for any costs charged to you by telephone operators in connection with the use of the SIM card used by Geo+, whether due to incorrect configurations or technical or other problems.

For technical issues, please send an email to: [ict@vebireu](mailto:ict@vebireu)